

How To: Clean the Screen


Keep your screens clean and the revenue will stay up... nobody wants to ride a dirty machine!!

1



Sometimes things get caught in the ceiling screen. Please keep this area clean!

2



There are three screws that need to be removed.

3



The screen hinges down for easy access. Hint: The sticky side of packing tape will remove lint easily!

4



Secure the door when clean!

5



There is another screen on the bottom of the machine. It is important to clean underneath or the machine can't breathe!

note

A dirty machine make you make less money!

Please wipe down the machine inside and out as needed especially if soda etc. is spilled. Let us know if your door graphics get beat up and need replacing.

Any trouble, just email us!
Service@hurricanesimulator.com

www.hurricanesimulator.com/service.html